

FLOWMASTER AMERICAN THUNDER SYSTEM

#17339

1994-1997 HONDA ACCORD EX 2.2L

REMOVAL:

1) SUPPORT THE STOCK MUFFLER WITH A STAND OF SOME TYPE, THEN SEPERATE THE THREE HANGER RODS FROM THE RUBBER MOUNTS ON THE VEHICLE. (A LUBRICANT WILL MAKE THIS EASIER)

2) USE A 12MM SOCKET WRENCH TO REMOVE THE TWO SPRING LOADED BOLTS AT THE MUFFLER INLET PIPE FLANGE. KEEP THE BOLTS AND SPRINGS.

INSTALLATION:

1) SLIDE THE NEW INLET PIPE OVER THE REAR AXLE AND ONTO THE FACTORY FLANGE CONNECTION. INSTALL THE STOCK BOLTS AND SPRINGS AND TIGHTEN DOWN UNTIL SHOULDER OF BOLTS BOTTOM OUT. SLIP THE HANGER ROD THROUGH THE RUBBER MOUNT TO SUPPORT THE PIPE.

2) INSERT THE TWO HANGER RODS AT THE BACK OF THE MUFFLER INTO THE FACTORY RUBBER MOUNTS. THEN SLIP THE INLET OF THE MUFFLER ONTO THE INLET PIPE. PLACE A 2" CLAMP ONTO THE INLET NECK CONNECTION, AND TIGHTEN

JUST ENOUGH TO HOLD IN PLACE. THEN PLACE STAINLESS TIP #ST339 ON OUTLET OF MUFFLER. ROTATE AND ADJUST DEPTH TO YOUR SATISFACTION THEN TIGHTEN CLAMP ON TIP TO HOLD IN PLACE.

3) ADJUST THE POSITION OF ALL PIECES TO GET A SATISFACTORY FIT, THEN TIGHTEN DOWN THE MUFFLER CLAMP SECURELY AND INSTALL THE PROVIDED HANGER KEEPER ONTO THE FRONT HANGER ROD. FOR A CLEANER LOOK, THE INLET CONNECTION CAN BE WELDED AND THE CLAMP REMOVED.

PACKING LIST

QTY.	PART#	DESC.
1	952060-162	MUFFLER
1	16370	INLET PIPE
1	ST339	STAINLESS TIP
1	PK383	PARTS KIT
1	MC200S	2" CLAMP
1		3/8" HANGER KEEPER

