



**2010-2012 Mustang GT
Transmission Cooling Scoop M-5025-MBR
SUPPLEMENT INSTRUCTIONS**

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF
FORD RACING PERFORMANCE PARTS

!!! PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY PRIOR TO INSTALLATION !!!

Caution: If you are not confident that you can complete the installation safely, have it completed by a certified technician! Failure to complete the installation correctly could cause damage to your vehicle.

For installation of Transmission Cooling Scoop M-5025-MBR on a standard 2010-2012 Mustang GT, please utilize the 2012 Mustang Boss 302 Laguna Seca Edition Transmission Cooling Scoop Installation Instructions.

Techline (800) FORD788

Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356



2012 Mustang Boss 302 Laguna Seca Edition Transmission Cooling Scoop M-5025-MBR INSTALLATION INSTRUCTIONS

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF
FORD RACING PERFORMANCE PARTS

!!! PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY PRIOR TO INSTALLATION !!!

Caution: If you are not confident that you can complete the installation safely, have it completed by a certified technician! Failure to complete the installation correctly could cause damage to your vehicle.



PARTS IN KIT:

Quantity	Part Name
1	Transmission Cooling Scoop

Techline (800) FORD788

Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356

2012 Mustang Boss 302 Laguna Seca Edition Transmission Cooling Scoop M-5025-MBR INSTALLATION INSTRUCTIONS

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF
FORD RACING PERFORMANCE PARTS

INSTALLATION INSTRUCTIONS:

STEP 1: Support the vehicle to gain access to the undercarriage.

STEP 2: Remove the (4) nuts attaching the rear support brace to the sub frame.



STEP 3: Remove the rear support brace from the sub frame studs.



Techline (800) FORD788

Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356



2012 Mustang Boss 302 Laguna Seca Edition Transmission Cooling Scoop M-5025-MBR INSTALLATION INSTRUCTIONS

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF
FORD RACING PERFORMANCE PARTS

STEP 4: Install the new rear support brace / transmission duct over sub frame studs.



STEP 5: Install the (4) nuts onto the sub frame studs and tighten.



STEP 6: Torque (4) nuts to 46 ft.-lb.



Techline (800) FORD788

Factory Ford shop manuals are available from Helm Publications, 1-800-782-4356