



Instructions for KC #75001 Grille and C20 20" LED bar for Chevy Silverado 2011 - 13

Thanks for choosing a KC HiLiTES product. We take pride in building the highest quality, best engineered systems possible. Your satisfaction with our product is important, so if you have any questions, please call our customer service line at 800-528-0950. For warranty information, visit our website at www.kchilites.com.

PLEASE READ

- ***KC HiLiTES strongly recommends professional automotive & aftermarket accessory knowledge for proper installation of this grill.***
- ***You will be cutting the factory grill, returning back to stock may not be possible once completed.***

STEP 1 - Open the hood and remove clips holding radiator cover.

STEP 2 - Remove four 10mm bolts from top of stock grille.

STEP 3 - From behind, squeeze clips holding stock grille to supports.

STEP 4 - Take new grille and slide the four 1/4" studs through lower brackets on truck. Now slide top over radiator support.

STEP 5 - Before installing the new grille, install the LED bar and tighten securely. Ensure the LED cable is fed to a location that can easily be reached for connecting to the harness after the grille is in place.

STEP 6 - Center the grill between the headlights and put the four 10mm bolts back in top supports.

STEP 7 - On the four lower mounts, add a washer, then a 1/4" Nylok and tighten.

STEP 8 - Sometimes on the lower mounts, you may need to add one or two shims between the bracket and support so the grille will line up better with the headlights.

STEP 9 - Wire your LED bar according to the instructions included with the bar.

You're Done !!!



NOTE - Depending on vehicle manufacture date, it may require some cutting for light bar clearance.