



Instructions for KC #75050 Grille and C10 10" LED bar for Toyota Tacoma 2005 - 08

Thanks for choosing a KC HiLiTES product. We take pride in building the highest quality, best engineered systems possible. Your satisfaction with our product is important, so if you have any questions, please call our customer service line at 800-528-0950. For warranty information, visit our website at www.kchilites.com.

PLEASE READ

- KC HiLiTES strongly recommends professional automotive & aftermarket accessory knowledge for proper installation of this grill.
- You will be cutting the factory grill, returning back to stock may not be possible once completed.



NOTE - Depending on vehicle manufacture date, it may require some cutting for light bar clearance.



STEP 1 - Cut out center of grille using an air saw or jig saw as shown in photo at left.

STEP 2 - Line up small triangle pieces and drill a 3/16" hole for the stud as shown.

STEP 3 - Once grille is all cut out, remove brackets from the back of the factory grille and lay new grille over the face of the grille shell. Turn over and install brackets in the same location as they were removed. **NOTE - Before installing the new grille, install the LED bar and tighten securely. Ensure the LED cable is fed to a location that can easily be reached for connecting to the harness after the grille is in place.**

STEP 4 - Wire your LED bar according to the instructions included with the bar.