

110271 / 110272
10-11 CHEVY
CAMARO LS/RS



110271 / 110272
10-11 CHEVY
CAMARO LS/RS

2010-2011 CHEVY CAMARO LS/RS

T1 Series Center Console Tray

TOOLS REQUIRED:

Alcohol/Clean Rag

PARTS LIST:

1 T1 Series Center Console Tray

Step 1

Clean the area where the Console Tray will be installed with alcohol and a clean rag. Test fit the Console Tray.

Step 2

Peel adhesive backing off of the T1 Series Console Tray. Position the T1 Series Console Tray on top of the factory center tray as in the picture below. Push down on the Center Console Tray to ensure the adhesive sticks to the factory console tray.

