

110281 / 110282
10-11 CHEVY
CAMARO (ALL)



110281 / 110282
10-11 CHEVY
CAMARO (ALL)

2010-2011 CHEVY CAMARO (All)

T1 Series Center Console Cup Holder Trim

TOOLS REQUIRED:

Alcohol/Clean Rag

PARTS LIST:

1 T1 Series Center Console Trim

Step 1

Clean the area where the Cup Holder Trim will be installed with alcohol and a clean rag. Test fit the Cup Holder Trim.

Step 2

Peel adhesive backing off of the Cup Holder Trim. Position the Cup Holder Trim on top of the factory center tray as in the picture below. Push down on the Cup Holder Trim to ensure the adhesive sticks to the factory console tray.

