

11110

07-12 GM

TRUCKS & SUV's



11110

07-12 GM

TRUCKS & SUV's

07-12 GM Trucks & SUV's Console Cup and Cell Phone Holder Trim

TOOLS REQUIRED:

Alcohol/Clean Rag

PARTS LIST:

1 T1 Series Console Cup and Cell Phone Holder Trim

Step 1

Clean the area where the Trim Plate will be installed with alcohol and a clean rag. Test fit the trim plate. Remove the plastic backing on the adhesive on the back of the Console Cup and Cell Phone Holder Trim.

Step 2

Position the Console Cup and Cell Phone Holder Trim on top of the factory center console as in the picture below. Press down on the Console Cup and Cell Phone Holder Trim to ensure the adhesive backing adheres to the factory center console.

