

12518
10-12 FORD
MUSTANG
ALL MODELS



12518
10-12 FORD
MUSTANG
ALL MODELS

10-12 FORD MUSTANG

T1 Series Tail Light Trim 2 Pc.

TOOLS REQUIRED:

Rubbing Alcohol
Clean Rag

PARTS LIST:

(1) Tail Light Trim Kit (2 Pc.)

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE

INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Tail Light Trim Installation

First you will clean the vehicles tail lights with rubbing alcohol and a clean rag to ensure proper adhesion of the trims. Next peel the backing off of the tail light trim adhesive. Take the tail light trim and carefully line it up with the beveled edge of the tail light and press firmly to ensure the adhesive backing adheres to tail light. Press firmly around the trim. Repeat this process to the other tail light. Installation complete.

