



20084
04-07 CHEVY
KODIAK
4500

20084
04-07 CHEVY
KODIAK
4500

Hood Vent BILLET GRILLE

Recommended Tools:

Die Grinder W/ Cut-Off Wheel
Drill & 1/8" Drill Bit

Parts List / Hardware:

1 Billet Inserts (8 Bars)

Read and understand instructions before attempting installation

Step 1

Remove the grille shell from the vehicle. At this time the grille mesh may be cut from the opening. Make your cuts on the inside edge; where the mesh meets the outer perimeter of the opening. The billet will rest inside the inner edge when installed.

Step 2

Center the billet into the opening of the grille shell. Hold the billet in place. Drill a 1/8" hole aligned with the mounting tabs on top and bottom (4 total). Use the rivets to secure the billet in place.

Step 3

Re-install the grille assembly back onto the vehicle. Installation is now complete.

Thank you for purchasing your T-Rex billet grille. 6/17/05

