

20512

99-02 FORD
MUSTANG
HOOD SCOOP



20512

99-02 FORD
MUSTANG
HOOD SCOOP

Tools Required:

Phillip Screw Driver
Drill or Drill Gun
1/16" Drill Bit

Parts List:

1 - Hood Scoop Billet Insert (5 Bars)
2 - #8 x 1 Screws (#6 Head)

Read and understand instructions before attempting installation

Step 1

Do not remove plastic insert from inside the hood scoop. Center the billet into the opening. Lift up on the upper edge of the hood scoop and push the billet into the opening allowing the raised pins on top of the billet to pop in behind the lip in the hood scoop. Be careful not to scratch the paint. Drill a hole into the factory hood scoop insert at each mounting bracket and then fasten using the #8 screws; Or simply install the screws using a drill gun to fasten the hood scoop to the factory plastic insert (***Do not over tighten***). The insert will stay firmly in position. Installation complete. ***Thank you for purchasing a T-Rex billet grille.***