

10-12 NISSAN ALTIMA SEDAN

Billet Grille

TOOLS REQUIRED:

Socket and Ratchet Set
Flathead/Phillips Screwdrivers

PARTS LIST

(2) 1/4" Lock Washers
(2) 1/4" Flat Washers
(2) 1/4" Nuts
(2) 1/4" Bolts
(2) 1 1/4" #8 Button Head Screws
(2) #8 Nylon Nuts
(1) Billet Grille

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Factory Grille Removal

Remove the six plastic pop clips on the top of the radiator cover with a flat screwdriver (Fig 1). Unlatch two latches on the top corners of the factory grille, they hold the grille to the bumper cover (Fig 2). Pull the top of the factory grille forward and reach behind the factory grille. There are six plastic latches holding the factory grille to the bumper cover along the bottom edge of the factory grille. Use your hands and a flat screwdriver if necessary to unlatch these six latches. The factory grille should now be loose and you can fully remove it (Fig 3).

Step 2 Billet Grille Installation

Take the two white plastic #8 Nylon Nuts from the included parts bag and insert them into the inner two rectangular holes in the lower edge where the factory grille was removed from (Fig 4). Now take the billet grille and insert it into the opening where the factory grille was removed from. On the top of the billet grille are two aluminum arms with holes in them, take the 1/4" bolts and install the 1/4" lock washers onto them and then the 1/4" flat washers next. Take the bolt with the washers on it and insert them through the holes in the arms on the billet grille and the holes in the radiator core support (Fig 5). Reach under the core support where the bolts are inserted and install the two 1/4" nuts and tighten. Now take the two #8 Button Head Screws and insert them through the billet bars and a small square bracket with a hole in the center that is welded onto the backside of the billet grille, the screws will screw into the nylon nuts in the bumper cover that you installed earlier (Fig 6) tighten. Installation complete.

