

20797
03-07 INFINITI
G-35 COUPE



20797
03-07 INFINITI
G-35 COUPE

BILLET INSERT

Tools Required:

Small Slotted Screwdriver
7/16" Wrench

Part List:

- 1 Billet Insert (13 bars)
- 2 1/4-20 x 3/4 Bolts
- 2 1/4-20 Nuts
- 2 1/4 Washers

Read and understand instructions before attempting installation

Step 1.

Remove the factory grille shell; use a small screwdriver to pull the center from each fastener. Two of the fasteners will be re-used; do not discard the fasteners. Next, lightly pull the top of the grille assembly forward. There is one clip in each corner of the factory grille. Depress each clip by hand or with a screwdriver. Use your fingers to depress the molded clips along the bottom of the grille. The grille can now be removed.

Step 2.

Center the billet insert into the opening. The lower mounting tabs align into the factory holes. Use a 1/4" bolt, nut and washer to secure the lower tabs. Use the factory fasteners to attach the upper mounting brackets. These brackets align to the factory holes also. It may be necessary to slightly bend the upper brackets so they align correctly.

Step 3.

Close the hood and check the alignment of the billet insert. If necessary, remove the insert and adjust the brackets. ***Thank you for purchasing a T-Rex Billet Grille. 6/30/06***

