

20880

98-00 TOYOTA
T A C O M A
Billet Grille Insert
ALL MODELS



20880

98-00 TOYOTA
T A C O M A
Billet Grille Insert
ALL MODELS

97-00 TOYOTA TACOMA 2WD MODELS

98-00 TOYOTA TACOMA 4WD MODELS

NOTE: This billet replaces the factory grille shell.

Tools Required:

Phillips screwdriver
Drill & 3/16" Drill Bit

Hardware / Parts Included:

1 Billet Grille Insert (15 bars)
4 #8 x 3/4 Phillip Screws
4 #8 Flat Nuts

Read and understand instructions before attempting installation

NOTE: THIS BILLET INSERT REPLACES THE ENTIRE GRILLE SHELL.

Step 1.

Open the hood and remove the factory grille shell by removing the factory retaining clips.

Step 2.

Center the billet insert into the opening. The brackets mount near the factory mounting location on the radiator support (it may be necessary to slightly bend the brackets to get a perfect fit). Drill a 3/16" hole into the radiator support to fasten the upper mounting brackets. Secure the billet insert to the truck using the screws and flat nuts.

Step 3.

Make sure the billet is centered in the opening and all fasteners are tight. Installation is now complete.
Thank you for purchasing a T-Rex Billet Grille. 12/2/05