

12-13 Chevrolet Sonic

Upper Class Billet Grille

Install time: 35 Mins.

TOOLS REQUIRED:

Screwdriver
1/4 Drillbit

PARTS LIST:

(2) Billet Grilles
(4) 6/32 1.5" Machine Screws
(4) Spring Wing Clips

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.

- Insert 1.5" Machine Screws through the Brackets on the Billet Grille. (Fig. 1)
- Thread a Spring Wing Clip onto the Machine Screw (Thread many times). (Fig. 2)
- Place the Billet Grille through the Factory Grille. (Fig. 3)
- Start Threading the Machine Screw so the Spring Wing Clip holds onto the Factory Grille (Pull Grille Outward to hold Spring Wing Clip in Place). (Fig. 4)
- To remove the Licence Plate, Remove the 2 screws that are on top and Use the 1/4 Drillbit to Drill through the center of the Bolts once you remove the License. (Fig. 5)
- Remove the License Plate. (Fig. 6)
- Repeat Fig. 1-4 for lower grille.

Installation Complete

