

21275

98-04 CHEVY
S-10 TRUCK



21275

98-04 CHEVY
S-10 TRUCK

1998-2004 S-10 TRUCK and BLAZER
With Factory "Lines Design" Grille

Tools Required:

Phillips screwdriver

Hardware / Parts Included:

- 1 Upper Billet Insert (8 bars)
- 1 Lower Billet Insert (8 bars)
- 4 #8 x 1.25" Screws (#6 Head)
- 4 #8 U-Nuts
- 4 2" Flange Brackets

Read and understand instructions before attempting installation

Step 1.

Your vehicle should have two chrome bars across the factory grille; one just below the hood and one across the center of the grille. Open the hood and remove the factory grille. Test fit the billets in place to identify the upper and lower billet inserts.

Step 2.

Slide the u-nuts onto the flange brackets. Note the two tabs welded to each of the billet inserts. Insert a screw into each tab. Place the lower insert in the factory grille. Center the insert and hold in place. Secure the billet from behind the factory grille using the flange brackets. Do not over-tighten the hardware.

Step 3.

Repeat Step 2 on the upper insert. Re-install the grille assembly back on the vehicle.

Thank you for purchasing a T-Rex Billet Grille. 916106