



21285

05-08 CHEVY
EQUINOX

21285

05-08 CHEVY
EQUINOX

05-08 CHEVROLET EQUINOX
BILLET OVERLAY – 2 PC

Tools Required:

Phillips Screwdriver
Slotted Screwdriver

Hardware Provided / Parts:

1 Billet Overlay - Top (5 bars)	12 #8 U-Nuts
1 Billet Overlay - Bottom (12 bars)	12 2" Flange Brackets
12 #8 x 1.25" Screws (#6 Head)	

Read and understand instructions before attempting installation

Step 1.

The grille is part of the bumper cover assembly. The grille is not removed; however it will need to be loosened to access the rear of the grille. Remove the four plastic fasteners securing the top plastic grille mesh. These are on top of the core support. There is a metal retaining clip behind the chrome strip on each end. Use a flat screwdriver (wrap in a rag to prevent scratching) to pull the chrome strip forward. It will take some force to dislodge. Gently pull the grille forwards. Just behind the grille is a plastic air box that must be removed to install the grille. This will be re-installed later.

Step 2.

Slide a u-nut onto each black flange bracket; the non-threaded side of the u-nut installs on the 'C' shaped cupped area of the flange bracket.

Step 3.

Take the lower billet insert and install a screw into the mounting tabs. Center the billet over the lower grille mesh. Gently pull the bumper cover / factory grille forwards to gain access to the rear of the grille. Re-center the billet over the mesh; now use the flange brackets / u-nuts to secure the billet. Do not over tighten the screws. Repeat this process on the upper billet insert. Re-install the air box assembly. Secure the metal clips behind the chrome strip. Re-install the plastic fasteners retaining the bumper cover. ***Thank you for purchasing your T-Rex billet grille.***

11/6/06

