

**21442
21442B
11-13 DODGE
CHARGER**



**21442
21442B
11-13 DODGE
CHARGER**

11-13 DODGE CHARGER

Billet Grille Overlay/Bolt on - 4 Pc.

TOOLS REQUIRED:

Screwdriver

PARTS LIST:

- (4) Billet Grilles
- (8) 6/32 1.5 Machine Screws
- (8) Spring Wing Clips

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.

Step 1

Insert a 6/32 1.5 Machine Screw through the brackets on the Billet Grille and thread a Spring Wing Clip on. (Thread many times so the Spring Wing won't get loose and fall off.) (Fig. 1)

Place the Billet Grille over the Factory Grille and have the Spring Wings face horizontal. (Make sure the Billet Grille is on the right way.) With semi-force, Push the Spring Clip through the Factory Grille. (Fig. 2)

With a Screwdriver and holding the Billet Grille outward so the Spring Clip won't twist around, Start threading the Machine Screw. (Fig.3)

Installation Complete

