

21491/21491B

11-13 DODGE DURANGO



21491/21491B

11-13 DODGE DURANGO

11-13 DODGE DURANGO

Upper Class Billet Grille 4 Pc.

Install time: 35 Mins.

TOOLS REQUIRED:

Screwdriver
Plastic Prybar

PARTS LIST:

(4) Billet Grilles
(8) 6/32 1.5 Machine Screws
(8) Spring Wing Clips

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.**

Step 1

- Insert a 6/32 1.5 Machine Screw through the brackets on the Billet Grille and thread a Spring Wing Clip on. (Thread many times so the Spring Wing wont get loose and fall off.) (Fig. 1)

Step 2

- Place the Billet Grille over the Factory Grille and have the Spring Wings face horizontal. (Make sure the Billet Grille is on the right way.) With semi-force, Push the Spring Clip through the Factory Grille. (Fig. 2)

Step 3

- With a Screwdriver and holding the Billet Grille outward so the Spring Clip wont twist around, Start threading the Machine Screw. (Fig. 3)
- For the Dodge Logo, Just Unclip with a Plastic Prybar or Flat Screwdriver.
- Repeat for remaining Billet Grilles.

Installation Complete

