

21932

**07-13 TOYOTA
FJ CRUISER
BILLET INSERT**



21932

**07-13 TOYOTA
FJ CRUISER
BILLET INSERT**

2007-2013 TOYOTA FJ CRUISER ***BILLET OVERLAY W/ LOGO CUT-OUT***

Tools Required:

Phillips screwdriver

Hardware / Parts Included:

- 1 Billet Insert (12 bars)
- 4 #8 x 1.25" Screws (#6 Head)
- 4 #8 U-Nuts
- 4 2" Flange Brackets

Read and understand instructions before attempting installation

Step 1.

Open the hood; test fit the billet in front of the factory grille.

Step 2.

Slide the u-nuts over the hole in the flange brackets.

Step 3.

Insert the screws into the tabs welded to the billet. Secure the flange brackets from behind the grille. Secure the hardware (do not over-tighten). ***Thank you for purchasing a T-Rex Billet Grille. 9/11/06***

