

21933

07-13 TOYOTA
FJ CRUISER



21933

07-13 TOYOTA
FJ CRUISER

2007-2013 TOYOTA FJ CRUISER

Hood Scoop

Tools Required:

Phillips / Slotted Screwdrivers
Drill & 1/8" Drill Bit
5/16" Socket

Part List:

1 Upper Class Hood Scoop (Cruiser)
2 #10 Flat Washers
2 6-32 Nylon Lock Nuts

Read and understand instructions before attempting installation

Step 1.

Test fit the hood scoop insert in place. Drill two 1/8" holes into the factory insert; align these holes with the studs on the insert. Be careful not to scratch the paint on the hood. Masking tape may be applied to prevent scratching. Place a washer and nylon lock nut onto each stud. Making sure that the plate is centered, tighten the hardware. ***Thank you for purchasing a T-Rex Billet Grille. 08/25/08***