

21938
21938B
12-13 TOYOTA
TACOMA



21938
21938B
12-13 TOYOTA
TACOMA

12-13 TOYOTA TACOMA

Upper Class Billet Overlay Grille

Install time: 35 Mins.

TOOLS REQUIRED:

Screwdriver
Socket Wrench

PARTS LIST:

(2) Billet Grilles	(2) J-Hooks
(2) L-Brackets	(4) 2" Screws
(4) U-Nuts	

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.**

- Insert U-Nuts onto 2 of the L-Brackets and on the J-Hooks (place them over the Holes). (Fig.1)
- Insert The Lower Grille on the Factory Grille. (Fig. 2)
- Place a 2" Screw through the Bracket on the Billet Grille, From behind the Grille, Thread the J-Hook so it Latches onto the Factory Shell. (Fig. 3)
- Place the Top Grille on the Factory Grille. (Fig. 4)
- Place a 2" Screw through the Bracket on the Billet Grille, From behind the Grille, Thread the L-Bracket with the U-Nuts so it Latches onto the Factory Shell. (Fig. 5)

Installation Complete

