

25101

**03-06 CHEVY
SILVERADO**

**Fog Light
BUMPER INSERT**



25101

**03-06 CHEVY
SILVERADO**

**Fog Light
BUMPER INSERT**

2003-2006 SILVERADO **BUMPER FOG LIGHT BILLET INSERTS; 2 PC. SET**

Tools Required:

Phillips Screw Driver
Die Grinder W/ Cut-Off Wheel
Drill & 1/8" Drill Bit

Hardware / Parts Included:

2 - Billet Grille Insert (10 bars)
6 - #8 x 3/4" Phillip Screws
6 - #8 Flat Nuts

Read and understand instructions before attempting installation

Step 1.

Remove the factory fog lights. If not equipped with fog lights, use a die grinder cut the plastic in each opening. Identify the left and right bumper inserts. Test fit the billets into the openings.

Step 2.

Hold the billets in place and mark the bracket hole to the openings. Drill a 1/8" hole at each mark. Secure the billets using the screws and nuts provided. Make sure the billets are centered and tighten the fasteners.

Step 3.

Installation is now complete. *Thank you for purchasing a T-Rex Billet Grille.*