

25104

03-06 CHEVY

SILVERADO

SUPER SPORT

BILLET BUMPER

1 PC. CENTER



25104

03-06 CHEVY

SILVERADO

SUPER SPORT

BILLET BUMPER

1 PC. CENTER

Tools Required:

Flat Head Screw Driver or Needle Nose Pliers

Hardware / Parts List:

1 - Billet Insert (8 bars)

Read and understand instructions before attempting installation

Step 1

Remove the plastic insert in the center of the bumper cover. It is held in the opening with plastic rivet type fasteners. Do not discard these fasteners.

Step 2

Center the insert in the bumper opening. Align the tabs on the insert to the factory mounting holes. Secure the billet insert using the factory fasteners (not all of them are needed).

Step 3

Installation is now complete.

Thank you for purchasing your T-Rex billet grille.