

25105

03-06 CHEVY

SILVERADO

SUPER SPORT

BILLET 2 PC.

VENT OPENING



25105

03-06 CHEVY

SILVERADO

SUPER SPORT

BILLET 2 PC.

VENT OPENING

Tools Required:

Phillip Screw Driver

Drill

1/8" Drill Bit

Flat Head Screw Driver or Needle Nose Pliers

Hardware / Parts List:

2 - Billet inserts (8 bars each)

6 - #8 x 3/4 Phillips Screws

6 - #8 Flat Nuts

Read and understand instructions before attempting installation

Step 1

Remove the plastic inserts in the bumper cover. They are held in place with plastic rivet type fasteners.

Step 2

Match the inserts to the right and left opening (they will only fit one way). Center one of the inserts in the vent opening (it may be necessary to slightly bend the brackets so the insert fits properly. Mark the holes from the mounting tabs onto the vent opening. Repeat on the other side. From the rear of the bumper cover, drill a 1/8" hole at each mounting tab.

Step 3

Secure the billet inserts using the fasteners provided. Make sure the billet inserts are correctly aligned.

Step 4

Installation is now complete.

Thank you for purchasing your T-Rex billet grille.