

25265

04-13 CHEVY
COLORADO
BUMPER BILLET



25265

04-13 CHEVY
COLORADO
BUMPER BILLET

04-13 CHEVY COLORADO

Tools Required:

Phillip Screw Driver
Drill and 1/16" Drill Bit

Hardware / Parts List:

1 - Bumper Insert (7 bars)
2 - #8 x 1 Screws (#6 Head)

Read and understand instructions before attempting installation

Step 1

Take the bumper insert in hand; slide the billet into one side of the bumper opening with the shortest bar on the bottom. Push the billet to one side and slide the billet fully into the opening. Center the billet. Note the two tabs welded to the rear of the billet. These tabs align with the plastic bars in the bumper opening.

Step 2

Mark the holes in the tabs to the plastic bars in the bumper. Remove the billet. Drill a 1/16" hole at each mark.

Step 3

Re-install the billet into the opening. Fasten the billet using the screws provided. Do not over tighten the screws. *Thank you for purchasing your T-Rex billet grille.*