

25282

02-09 CHEVY
trailblazer
BUMPER INSERT



25282

02-09 CHEVY
trailblazer
BUMPER INSERT

2002-2005 CHEVY TRAILBLAZER (ALL) **2006-2009 CHEVY TRAILBLAZER LS (ONLY)**

Tools Required:

Phillip Screw Driver
Drill
1/16" Drill Bit

Parts list:

1 Bumper Insert (8 bars)
4 #8 x 1 Screws (#6 HEAD)
4 #8 Flat Nuts

Read and understand instructions before attempting installation

Step 1.

Remove the license plate from the vehicle. Place the insert in the bumper opening.

Step 2.

Make sure the billet is centered. Note the two tabs on both ends of the insert and mark the holes. Remove the insert and drill a 1/16" hole at each mark. Install a screw from the front and fasten a flat nut from the rear. Make sure the insert straight and the screws are tight.

Step 3.

Thank you for purchasing a T-Rex billet grille. 12/30/05