

25468

**06-08 DODGE
RAM TRUCKS
BUMPER BILLET**



25468

**06-08 DODGE
RAM TRUCKS
BUMPER BILLET**

2006-08 Dodge Ram Trucks **Bumper Billet Insert – Between Tow Hooks**

Tools Required:

Phillips Screwdriver
9/16" (or 15mm) Wrench / Socket with 6" Extension
½" Wrench / Socket

Hardware / Parts List:

- 1 Bumper Insert (5 Bars)
- 2 #8 x 1" Screws (#6 Head)
- 2 #8 U-Nuts
- 2 Long Z Bracket
- 2 ¼-20 Bolts, Nuts, Washers


Read and understand instructions before attempting installation

Step 1

This billet insert is designed for the new style 2006 Dodge Ram bumper fascia (shown below).

Step 2

Attach the two longer Z brackets to the bumper as shown; these attach to factory holes along the bottom of the bumper (1 & 2). Use the ¼-20 bolts, nuts and washers.



Step 3

Slide a u-nut onto the other end of the mounting brackets. Center the grille into the opening (The small mounting tabs sit towards the bottom of the opening). Attach the grille using the #8 screws.

Thank you for purchasing a T-Rex billet grille. 5/24/06

