

T-REX TRUCK PRODUCTS INC.

25583

(16583)

99-02 FORD

SVT / Lightning

BUMPER BILLET

25583

(16583)

99-02 FORD

SVT / Lightning

BUMPER BILLET

Tools Required:

Phillip Screw Driver

Drill

3/16" Drill Bit

Hardware / Parts Included:

1 - Billet Bumper Insert (14 Bars)

6 - #8 x ¾ Phillip Screws

6 - #8 Flat Nuts

Read and understand instructions before attempting installation

Step 1

Remove the plastic insert from the bumper opening.

Step 2

Carefully center the billet insert in the opening from the front. Mark the location of the six brackets on the billet insert. Drill a 3/16" hole at each mark. Fasten using the #8 screws and flat nuts.

Step 3

Installation of the billet bumper insert is complete. *Thank you for purchasing your T-Rex billet grille.*