



25709

06-08 HONDA
PILOT SUV

25709

06-08 HONDA
PILOT SUV

BUMPER GRILLE

Tools Required:

Phillips Screwdriver

Hardware / Parts Included:

- 1 Bumper Insert (8 Bars)
- 4 #8 x 1 Screw (#6 Head)
- 4 #8 U-Nuts
- 2 3/4" J Hooks
- 2 2" J Hooks

Read and understand instructions before attempting installation

Step 1

Slide the u-nuts onto the J hooks. Insert a screw into each tab welded to the billet. Thread the J hooks onto the screws.

Step 2

Center the billet into the opening; Wrap the longer J hooks around the bottom of the bumper opening. Secure the short J hooks to the top. **T-Rex Billet Grilles 4/25/06**

