

25767

10-12 NISSAN ALTIMA SEDAN



25767

10-12 NISSAN ALTIMA SEDAN

10-12 NISSAN ALTIMA SEDAN

Billet Bumper Grille

TOOLS REQUIRED:

Socket and Ratchet Set
Flathead/Phillips Screwdrivers

PARTS LIST

(2) 1" J-Hooks
(2) 2" Screws
(2) 6/32" Nylon Lock Nuts
(1) Billet Grille



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Factory Grille Removal

Remove the six plastic pop clips on the top of the radiator cover with a flat screwdriver (Fig 1). Unlatch two latches on the top corners of the factory grille, they hold the grille to the bumper cover (Fig 2). Pull the top of the factory grille forward and reach behind the factory grille. There are six plastic latches holding the factory grille to the bumper cover along the bottom edge of the factory grille. Use your hands and a flat screwdriver if necessary to unlatch these six latches. The factory grille should now be loose and you can fully remove it (Fig 3).

Step 2 Billet Grille Installation

Take the billet grille and insert it into the factory bumper opening (Fig 4). Take the two 2" screws and insert them through the billet bars and the small square tabs with a hole in the center that are welded onto the back of the billet grille (Fig 5). From behind the billet grille take the two 1" J-hooks and reach behind the billet and slide the end with the hole in it over the screws you just inserted. The hook end of the J-hooks will latch around the inner lip of the bumper cover, now take the two 6/32" nylon lock nuts and install them onto the screws over the j-hooks and tighten. Reinstall the factory grille.

