

25791
04-10 INFINITI
QX56



25791
04-10 INFINITI
QX56

BUMPER INSERT

(Will not work with speed sensing cruise control)

Tools Required:

Phillip Screw

Hardware / Parts List:

- 1 Billet Insert (14 bars)
- 4 6-32 x 2" Machine Screws
- 4 #8 U-Nuts
- 4 1.5" J Hooks

Read and understand instructions before attempting installation

Step 1

Do not install this bumper billet insert if your vehicle is equipped with speed sensing cruise control. Open the hood of the vehicle. Test fit the bumper insert into the opening. Remove the grille. Install the U-nuts onto the J hooks supplied in the hardware.



Step 2

Insert the mounting screws into the tabs on the billet insert (noted by the arrow in the diagram). Start to thread the J hooks onto the screws from behind the billet grille.

Step 3

Re-center the bumper billet insert over the plastic vertical bars in the bumper opening. Reach from behind the bumper and wrap the hooks around the plastic bars as shown here in the picture. Use a Phillips screw driver to tighten the hardware.

Thank you for purchasing your T-Rex billet grille.

T-Rex Truck Products Inc. 6/30/06