

44491
46491
11-13 DODGE
DURANGO



44491
46491
11-13 DODGE
DURANGO

11-13 DODGE DURANGO

Upper Class 4 Pc Mesh Overlay

Install time: 35 Mins.

TOOLS REQUIRED:

Socket Wrench
Plastic Prybar

PARTS LIST:

(4) Mesh Grilles
(16) 6/32 Flange Nuts
(16) Threaded J-Hooks
(16) Fender Flatwashers

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.**

NOTE: IT MIGHT BE A TIGHT SQUEEZE

Step 1

• Unclip the Plastic Cover above the Factory Grille Shell. (Fig. 1)

Step 2

• Place Mesh Grille over the Factory Grille. (Fig. 2)

Step 3

• From Behind the Grille, insert a Fender Flatwasher through the Threaded Screw on the Mesh Grille and Thread with a 6/32 Flange Nut. (Fig. 3)

• To Remove the Dodge Logo: Use a Plastic Prybar or Flat Screwdriver to unclip.
Repeat for remaining Mesh Grilles.

Installation Complete

