

55416
52416
11-14 DODGE
CHALLENGER



55416
52416
11-14 DODGE
CHALLENGER

11-14 DODGE CHALLENGER

Bumper Mesh Grille

Install time: 35 Mins.

TOOLS REQUIRED:

10mm Socket
7mm Socket
Flathead Screwdriver

PARTS LIST:

(1) Mesh Bumper Grille
(6) 6/32 Nylon Lock Nuts
(6) Fender Flatwashers

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.

Step 1

- Remove (9) 7mm Screws, (2) 10 mm Bolts and 10 Clips from underneath the Bumper Cover. (Fig. 1)
 - Remove 2 Clips from Bottom Side Fender. (Fig. 2)
 - Remove Bumper Cover.
 - Place Mesh Grille through the bumper opening. (Fig. 3)
- From underneath the car, place the Fender Flatwashers behind the Mesh Grille on the Threaded Screws.
- Thread with the 6/32 Nylon Lock. (Fig. 4)
- Repeat for remaining Threaded Screws.
Re-Assemble Bumper Cover.

Installation Complete

