

54054

**07-13 CHEVY TAHOE
SUBURBAN/AVALANCHE**



54054

**07-13 CHEVY TAHOE
SUBURBAN/AVALANCHE**

07-13 Tahoe/Suburban/Avalanche **Hood Trim**

TOOLS REQUIRED:

Masking tape
Alcohol and clean rag

PARTS LIST:

1 Stainless Steel Hood Trim

Step 1

Center the front hood trim plate in place. Mark each corner edge with a piece of tape. Clean the area where the hood trim will be placed with alcohol and a clean rag. Peel the tape off of the backside of the hood trim. Align the hood trim to the vehicle and apply pressure to the hood trim until it is secure to the hood. Installation complete.