

54132
51132
12-13 Chevy
Sonic



54132
51132
12-13 Chevy
Sonic

12-13 Chevrolet Sonic

Upper Class Mesh Grille

Install time: 35 Mins.

TOOLS REQUIRED:

Screwdriver
1/16 Drillbit
1/4 Drillbit
Torx Bit #127

PARTS LIST:

(2) Mesh Grilles
(13) #8 1 1/4" Torx Flat Screws

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.**

- Place the Mesh Grille over the Factory Grille. (Fig. 1)
- With the 1/16 Drillbit, Drill through the holes that are on the Mesh Grille. (Fig. 2)
- Place the provided #8 Screws through the holes to Thread the Mesh Grille. (Fig. 3)
- To remove the Licence Plate, Remove the 2 screws that are on top and Use the 1/4 Drillbit to Drill through the center of the Bolts once you remove the License. (Fig. 4)
- Remove the License Plate. (Fig. 5)
- Repeat Fig. 1-3 for lower grille.

Installation Complete

