

54210
11-12 GMC
SIERRA HD



54210
11-12 GMC
SIERRA HD

11-12 GMC SIERRA HD

Upper Class Overlay Mesh Grille

TOOLS REQUIRED:

Phillips Screwdriver
Socket & Ratchet set
Plastic Prybar

PARTS LIST

(1) Mesh Grille
(4) 4.5 L-Brackets
(5) 1.5 L-Brackets
(9) 6/32 Nylon Lock Nuts

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.

Step 1

Remove (10) clips from plastic cover. (Fig, 1)
Remove plastic cover.
Remove (4) 10mm bolts along the top of grille. (Fig, 2)

Step 2

Place overlay grille on factory grille. (Fig, 3)

Step 3

Insert L-bracket so it latches onto plastic bar (Fig, 4)

Step 4

Insert 6/32 Nylon Lock Nut through threaded screw (Fig, 5)
(repeat for remaining screws)

Step 5

Install (4) 4.5 L-Brackets above the overlay grille. (Fig. 6)
Re-Install the (4) 10mm Bolts through the (4) 4.5 L-Brackets
along the top of grille.
Re-Install the plastic cover

Installation Complete

