

54408

11-13 CHRYSLER 200



54408

11-13 CHRYSLER 200

11-13 CHRYSLER 200

Upper Class Mesh Grille

TOOLS REQUIRED:

Plastic Prybar
Ratchet & Socket Set
Screwdriver

PARTS LIST:

(1) Mesh grille
(6) 6/32 Nylon Lock Nuts
(6) 10/32 Flatwashers
(2) Christmas Tree Clips
(1) Top Plate

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.

Step 1

Remove 7 Clips and 2 bolts along the top of the Factory Grille. (Bolts will be re-used.) (Fig. 1)

Lift up the Plastic Cover to remove a Torx Screw that connects the Factory Grille to the Factory Grille Shell. (Fig. 2)

Remove 2 Screws along the bottom of the Factory Grille. (Fig. 3)

Lift the Factory Grille upwards and pull out to remove the Grille. (Fig. 4)

IF BOUGHT WITH BUMPER, INSTALL BUMPER AT THIS POINT.

Insert the top plate along the 4 Short Screws on the Mesh Grille & Insert 10/32 Flatwashers, Thread with 6/32 Nylon Lock Nuts. (Fig. 5)

Place 10/32 Flatwashers on the 2 Screws along the bottom of the Mesh Grille and Thread with 6/32 Nylon Lock Nuts. (Fig. 6)

On the corners of the Top Plate, Insert the Factory Bolts back in. (Fig. 7)

On the 2 middle holes on the Top Plate, Insert the Christmas Tree Clips and Factory Intake Clip back in. (Fig. 8)

Installation Complete

