

09-11 HYUNDAI GENESIS

Upper Class Mesh Grille

TOOLS REQUIRED:

Socket and Ratchet Set
Flathead/Phillips Screwdrivers

PARTS LIST

(5) #10 Flat Washers
(7) 6/32" Nylon Lock Nuts
(1) 2" Custom Hyundai Bracket
(1) Upper Class Mesh Grille
(1) Top Plate



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Factory Grille Removal

Open the hood. Remove the twelve plastic pop clips from the black plastic cover plate that is attached to the upper front of the engine compartment by pressing in the center of the pop clip with a pointy object (Fig 1) and pulling the pop clip out of the cover plate. There are also two 10/32" bolts that need to be removed from same plastic cover plate. Remove the plastic cover plate from the vehicle (Fig 2). Now remove two more plastic pop clips (one on each side) from the bumper cover top edge between the factory grille and the headlamps (Fig 3). Remove two phillips screws from the backside of the upper right/left corners of the factory grille, use a small ratcheting phillips screwdriver (Fig 4). There are two more phillips screws located on the back of the factory grille, they are located below the screws you just removed (Note these are a little difficult to reach). Now reach down behind the factory grille and locate the six plastic latches along the bottom and sides of the factory grille. Use your hands or a small flat screwdriver to unlatch them. Pull the factory grille forward and remove it from the vehicle.



Step 2 Upper Class Grille Installation

Now take the top plate and install it onto the mesh grille, the downward bent tabs will slide over the threaded studs on the mesh grille (Fig 5). Install flat washers and nylon lock nuts onto the four outside threaded studs to secure the top plate. Now take the custom bracket from the parts bag and insert the 90 degree bent end into the gap between the plastic bumper cover and the impact foam in the center bottom of the factory grille opening (Fig 6). Now take the mesh grille and insert it into the factory grille opening, the bottom center threaded stud will insert through the lower hole in the custom bracket, install a 6/32" nylon lock nut on it (Fig 7 upper arrow). Now take the factory grille and remove the chrome vertical trim from the center of the front of the grille by removing the screws on the back, keep the screws as you will need them later. Install the trim onto the center front of the mesh grille, use the factory screws and a flat washer from the parts bag on the backside of the trim to secure it to the mesh grille (Fig 8). Reinstall the plastic pop clips in the bumper cover area in Fig 3 and the radiator cover, use the plastic pop clips you removed earlier to secure the top plate and the radiator cover to the vehicle (Fig 9). The top plate will be on top of the radiator cover and sit in the indents in the radiator cover. Installation complete.

