

54524
09-12 FORD
FLEX



54524
09-12 FORD
FLEX

09-12 FORD FLEX

Upper Class Series Side Vents

TOOLS REQUIRED:

Alcohol/Clean Rags

Tape

PARTS LIST:

2 Side Vents

Step 1

Read and understand all instructions before attempting the install of this grille. Be sure that the package of hardware matches the hardware list as listed above. Next, test fit the T-REX side vent to the vehicle. You are now ready for the install:

Step 2

Clean the designated area of the vehicle where the vent will adhere using a clean rag and alcohol. Place the vent to the vehicle. Mark the desired position of the vent using tape as a guild. Making sure that the area is even and clean, peel the tape backing. Place the vent to the vehicle. Place pressure to the vent until it adheres to the vehicle. Repeat this process to the other side of vehicle. The vents should look like the picture below when finished.

