

54897
05-10 TOYOTA
TACOMA



54897
05-10 TOYOTA
TACOMA

UPPER CLASS SERIES HOOD SCOOP

Tools Required:

Phillips Screwdriver
5/16 Socket
Drill & 1/16" Drill Bit

Hardware / Parts List:

- 1 Upper Class Hood Scoop
- 2 6-32 Nylon Lock Nuts
- 2 #6 Flat Washers
- 3 'T' Plastic Fasteners (20180)

Read and understand instructions before attempting installation

Step 1

Remove the Phillips screw and bolts under the hood scoop; remove the assembly. Disassemble the metal screen from the hood scoop; drill out the rivets securing the screen in place.

Step 2

Center the grille over the metal screen. Use the nuts and washers to secure the grille. Center the grille and screen into the hood scoop; use the plastic fasteners to secure the screen assembly. Re-install the hood scoop assembly onto the vehicle. *Thank you for purchasing your T-Rex billet grille.* T-Rex Truck Products Inc. 10/24/06

