

54962
10-12 TOYOTA
TUNDRA



54962
10-12 TOYOTA
TUNDRA

10-12 TOYOTA TUNDRA

Upper Class Top Grille Accent

TOOLS REQUIRED

Phillips screwdriver

PARTS LIST

(4) #8 - 1" 6 Head Screws Polished

(1) Upper Class Hood Accent

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Install

Take the hood trim and place it into the upper most factory grill opening. (Fig 1) Now take the four #8 screws and install them into the 4 small holes along the hood accent. (Fig 2) Use a phillips screwdriver to tighten the screws. Installation complete.

