

55492
52492
11-13 DODGE
DURANGO



55492
52492
11-13 DODGE
DURANGO

11-13 DODGE DURANGO

Upper Class Mesh Bumper

Install time: 35 Mins.

TOOLS REQUIRED:

Socket Wrench

PARTS LIST:

- (1) Mesh Grille
- (4) L-Brackets
- (4) 6/32 Nylon Lock Nuts

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

Step 1

- From Underneath the Bumper Cover, Remove (2) 10mm Bolts and (2) Circular Clips. (Fig. 1)

Step 2

- Slide out the Bumper Cover to slide your hand Through. (Fig. 2)

Step 3

- Place Mesh Grille through the Bumper Opening. (Fig. 3)

Step 4

- Insert the L-Brackets on the Threaded Screws on the Mesh Grille (L-Bracket will face towards the Factory Bumper Grille to Latch onto) Thread with 6/32 Nylon Lock Nut. (Fig. 4)

- Thread the other 3 L-Brackets and Re-assemble the Bumper Cover.

Installation Complete

