

55518
10-12 FORD
MUSTANG



55518
10-12 FORD
MUSTANG

10-12 FORD MUSTANG

Upper Class Bumper Grille Base Models

TOOLS REQUIRED:

Socket and Ratchet Set
Flat/Phillips Screwdrivers

PARTS LIST:

(4) 2" Flange Brackets
(4) 6/32" Nylon Lock Nuts
(1) Upper Class Bumper Grille

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE

INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.



Step 1 Top Radiator Cover Removal

First you will remove the top radiator cover from the vehicle. There are 8 plastic pop clips on the radiator cover that need to be removed with a flat screwdriver by prying the head upward (Fig 1). Now you can remove the radiator cover. This will give you access to the rear of the factory bumper.

Step 2 Bumper Grille Installation

With the radiator cover removed, place the bumper mesh grille into the factory bumper opening (Fig 2). Reach down through the top where the radiator cover was removed and place the four 2" Flange Brackets over the threaded studs on the backside of the bumper mesh grille, the bent ends will face forward. Install the four 6/32" nylon lock nuts over the 2" flange brackets and tighten (Fig 3). Reinstall the radiator cover. Installation complete.

