

55590

**03-06 FORD
EXPEDITION**



55590

**03-06 FORD
EXPEDITION**

03-06 FORD EXPEDITION **UPPER CLASS SERIES MESH BUMPER**

TOOLS REQUIRED:

5/16" Wrench

PARTS LIST:

- 1 Mesh Bumper
- 4 6-32 Nylon Lock Nuts
- 4 #10 Flat Washers
- 4 1/2" x 1/2" L Brackets

Read and understand instructions before attempting installation

Step 1

Test fit the billet into the opening.



Step 2

Hold the billet in place. From the back of the bumper, install the flange brackets onto the mounting studs as shown. Use the washers and nuts to secure the grille. Do not over-tighten the hardware.

Thank you for purchasing a T-Rex Billet Grille. 9/11/06

