

2011 HONDA CRZ
Upper Class Bumper Mesh Grille

TOOLS REQUIRED:

Phillips Screwdriver
Drill & 1/8 Drill bit
Plastic Prybar

PARTS LIST

(2) 4' Flange Center Hole (2) Side Bumper Grilles
(3) 2' Flange Center Hole (1) Bumper Grille
(5) 6/32 Nylon Lock Nuts
(2) #8 Flatnuts
(2) #8 x 1.25' Screws (#6head)

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE
ATTEMPTING INSTALLATION.

Step 1

Remove 6 clips above grille shell. (Fig. 1)
Remove small plastic covers on corners. (Fig. 2)
Remove filler plastic. (Fig. 3)

Step 2

Remove 2 10mm bolts (one on each end of radiator cover) and 3
clips. (towards center) (Fig. 4)
Carefully pull bumper mounting tabs up to remove and slide off
radiator cover forward & out. (Fig. 5)

Step 3

Place bumper mesh onto factory bumper. (Fig. 6)
Insert (2) 4' Flange Brackets through the threaded screws along
top of mesh grille. (Brackets will be horizontal), Attach with Nylon
Lock Nuts (Fig. 7)
Insert (3) 2' Flange Brackets through the threaded screws along
bottom of mesh grille. (Brackets will be vertical) Attach with Nylon
Lock Nuts (Fig. 8)



Fig. 1



Fig. 2



Fig. 3



Fig. 4



Fig. 5



Fig. 6



Fig. 7



Fig. 8

2011 HONDA CRZ
Upper Class Bumper Mesh Grille

Step 4

Place one side bumper grille onto factory bumper, mark mounting bracket tab hole. With a 1/8 drill bit, drill the hole. (Fig. 9)

Place a #8 Screw through the threaded hole on grille mesh and insert a Flatnut behind the bumper so it threads onto the screw (Access from top of bumper)

Repeat other side (Fig. 10 & 11)

Re-install plastic covers, filler plastic, clips and bolts.

Installation Complete



Fig. 9



Fig. 10



Fig. 11