

52792/55792

52793/55793

**11-13 INFINITI
QX56**



52792/55792

52793/55793

**11-13 INFINITI
QX56**

2011-13 INFINITI QX56

Upper Class Bumper

TOOLS REQUIRED:

Socket & Ratchet Set

PARTS LIST

- (1) Bumper Grille
- (4) 135' Flange Brackets
- (4) 6/32 Nylon Lock Nuts

- Remove 4 Bolts underneath the Plastic Cover (2 Forward & 2 Far back). (Fig. 1)
- Lift Up the Plastic Cover and Remove.
- Place the Mesh Grille on the Factory Bumper Opening. (Fig. 2)
- From behind the Grille, Place the Flange Brackets on the Threaded Studs. (Fig. 3)

INSTALLATION COMPLETE

