

55992
09-11 BMW
3 SERIES



55992
09-11 BMW
3 SERIES

09-11 BMW 3 SERIES

Upper Class Series Bumper Grille

TOOLS REQUIRED:

Socket and Ratchet Set
Flat/Phillips Screwdrivers

PARTS LIST

(4) 135 Flange Brackets
(4) 6/32 Nylon Lock Nuts
(1) Bumper Grille

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Lower Front Splash Guard Removal

From under the front of the vehicle, remove the plastic splash guard. There are sixteen 8mm screws around the splash guard that need to be removed (Fig 1) as well as two 8mm screws connected to brackets (Fig 2). Remove the brackets and splash guard.

Step 3 Grille Installation

From the front of the vehicle, insert the mesh grille into the factory bumper opening (Fig 3). From the backside of the bumper cover locate the four threaded studs on the mesh grille and install the 135 flange brackets onto the threaded studs, the 6/32" nylon lock nuts will install on the threaded studs next, tighten the nuts (Fig 4). Reinstall the lower splash guard.



Fig 1



Fig 2



Fig 3



Fig 4