

Installation Instructions

Recommended Tools:

- Floor Jack
- Jack Stands
- Pry Bar
- 15mm and 18mm wrenches or sockets
- Torque Wrench



Installation Steps

1. Start by lifting the vehicle and supporting it under the cradle with the jack stands.
2. Remove the wheels to access the vertical links.
3. Remove the vertical link using the 15 mm wrench for the top bolt and the 18mm for the bottom bolt.
4. Install the new vertical link reusing the factory hardware.
5. Torque the lower bolt to 129 ft/lbs and the upper bolt to 81 ft/lbs.
6. Repeat steps 3-5 on the other side.
7. Install the wheels and torque to the proper settings for your wheels.

It must be noted that this product is sold for “offroad use only” and customer assumes all risks.