



S550/S650 Mustang Chassis Jacking Rails Installation Instructions

Parts List:

- (2) Jacking Rails – driver/passenger
- (8) M10-1.5 x 35mm flange bolts

Tools Needed:

- 15mm socket
- Ratchet



Installation Steps

1. Installation can be completed while vehicle is parked on the ground with parking brake engaged. If lifted is preferred, safely raise the vehicle and support using jack stands or lift, staying clear of both pinch welds.
2. Identify the driver side chassis jacking rail. Note that the driver side is slightly longer than the passenger side.
3. Locate the (2) body bolts behind the front wheel well and the (2) in front of the rear wheel well. (Images shown on convertible model)



Front



Rear

4. Using a 15mm socket, remove these four bolts from the body.

S550/S650 Mustang Chassis Jacking Rails Installation Instructions

5. Line up the jacking rail along the inside of the pinch-weld with these mounting holes. Using the removed bolts or the supplied hardware, thread each bolt loosely into place. Once all (4) bolts are started and jacking rail is lined up in place, tighten all (4) bolts.



Front



Rear

6. Repeat steps 3-5 on the passenger side.
7. Once all bolts are tightened, these chassis jacking rails can be used to safely and securely raise the vehicle.

