



**2010-2019 GM Silverado/Sierra 1500 V8, 4.8/5.3L
BlackHeart Cat-Back Exhaust System, 409SS
705014132RHKR
Installation Instructions**

***2010-13 FITS ALL CREW CABS & EXT. CAB w/ 6.6 FT. BED (143 WB)**
***2014-19 FITS CREW CAB w/ 5.75 FT. BED AND EXT. CAB w/ 6.6 FT. BED (143 WB)**



Thank you for making HOOKER HEADERS your choice in a high-performance exhaust system. Extensive dyno/track testing has enabled HOOKER to offer the most advanced design in exhaust systems. The installation, while not complex, will take a certain amount of time. However, the additional horsepower and improved performance will more than justify your efforts. Proper installation and maintenance will ensure long life and maximum performance from your HOOKER HEADER exhaust system.

BEFORE STARTING:

Your vehicle must be raised a minimum of 36 inches. A floor hoist is ideal. If no hoist is available, we strongly urge the use of axle stands as a safety measure. Please read these instructions in their entirety before attempting installation.

CAUTION! WORK ONLY ON A LEVEL SURFACE. USE JACKS /JACK STANDS OF SUFFICIENT CAPACITY TO LIFT AND SUPPORT YOUR VEHICLE. NEVER WORK UNDER A VEHICLE SUPPORTED BY A FLOOR OR BUMPER JACK.

INCLUDED HARDWARE:

P/N	Qty.	Description
556R23	3	Band Clamp, 3.0" x 1.25" Wide, 4.0 SS Torca
556R30	1	Swivel Seal 70MM 304SS
599R94	2	Decal - Blackheart 4" x 2"

Check the hardware package. If anything is missing, please contact Technical Service at 1-866-464-6553 or 270-781-9741.

INSTALLATION:

1. Disconnect the negative cable from the vehicle battery.
2. If necessary, lift the vehicle and secure on jack stands.
3. Loosen the OE swivel seal band clamp connecting the OE exhaust mid pipe to the OE Y-pipe.

4. Remove the (x4) rubber isolation mounts off the vehicle and remove OE exhaust.
5. On a workbench, transfer the rubber isolation mounts off the OE exhaust and onto the BlackHeart Cat-Back Exhaust System. We recommend transferring the isolation mounts one at a time to ensure they go back to their original positions.
6. Using (x1) supplied swivel seal, install the BlackHeart Mid Pipe with flex pipe to the OE Y-pipe and secure the rubber isolation mount to the chassis. Do not tighten the swivel seal.
7. Using (x1) supplied 3.0" band clamp, install the BlackHeart Muffler Inlet Pipe over the mid pipe. Do not tighten the band clamp.
8. Using (x1) supplied 3.0" band clamp, install the BlackHeart Muffler Assembly over the inlet pipe and secure the rubber isolation mounts onto the chassis. Do not tighten the band clamp.
9. Using (x1) supplied 3.0" band clamp, install the BlackHeart Tailpipe to the muffler assembly and secure the rubber isolation mount to the chassis. Do not tighten the band clamp.
10. Align the BlackHeart Exhaust System and tighten all band clamps from steps 6, 7, 8 and 9.
11. Connect the battery, start the engine, and check for leaks.
12. Re-check your work.
13. Remove the jack stands and lower the vehicle.
14. After 150 miles, re-check and tighten all bolts.

NOTE: It is normal for the Blackheart Headers to emit smoke for the first few minutes during break-in period.

LIMITATION OF LIABILITY – DISCLAIMER:

The regulation of emissions production, noise levels, and safety standards is undertaken by the federal government, each of the fifty state legislatures, and by many local municipalities, towns, and counties.

HOOKER™ makes no warranties of merchantability, of fitness for particular purpose, or that its products are approved for general use, or that its products comply with laws, regulations, or ordinances in the state where they may be sold to the ultimate purchaser, the consumer.

Unless expressly stated to the contrary in the catalog, instruction sheet; or price list, the entire risk as to the conformity of any company product in any such state and as to repair should the product prove to be defective or non-conforming, is on the retail purchaser, the buyer, the ultimate consumer, of such product and it is not upon the seller, distributor, or manufacturer.

In this connection, the retail purchaser, the buyer, the ultimate consumer assumes the burden of the entire cost of any and all necessary service, alterations, or repair.

THE FOREGOING STATEMENT LIMITS THE LIABILITY OF THE MANUFACTURER.

California vehicle code, sections 27156 and 38391, prohibits the advertising, offering for sale, or installation of any device, which modifies a vehicle's emission control system, unless exempted, unless otherwise noted. HOOKER™ Headers that have not received an Executive Order (E.O.) exemption from these code sections are not legal for sale or use in California on vehicles originally equipped with catalytic converters, except for racing vehicles, which may never be driven upon a highway. Check with your local authorities to determine if these headers are legal for use in your particular area.

© 2016 Hooker Headers, Inc. All rights reserved. Tous Droits Réservés.

199R11197

Revision Date: 11-23-20